

Replacing Batteries on your 4 Button Keyfob Remote



This information is provided so that, for your convenience, you can swap out batteries in a wireless device in your Smart Home Security System.

- 1) BEFORE you start tampering with your device, please call our Monitoring Center at (866)406-5787 to put the system in "test" mode. You will need your password to verify it is you, and not an unauthorized person calling. They will put the alarm in a suspended mode so that your activities will not set off a false alarm.
- 2) Using the below diagrams and instructions, you should be able to open the cover of the device and swap old batteries for new.
- 3) Please call our local office at (865)474-9495 if you have any questions or problems.

Inserting and Replacing the Battery

The key fob arrives ready to use (batteries already installed).


To replace the battery:

- 1 Remove the screw from the back of the keyfob.
- 2 Separate the keyfob's faceplate from its backplate.
- 3 Slide the existing battery out from under the metal battery clip on the printed circuit board.

IMPORTANT: Always dispose and/or recycle used batteries in accordance with the hazardous waste recovery and recycling regulations for your location. Your city, state, or country may also require you to comply with additional handling, recycling, and disposal requirements.


- 4 Insert the replacement battery into the metal battery clip on the printed circuit board. The plus (+) sign on the battery should be facing up and the minus (-) side facing down as illustrated below.

Figure 1 4-Button Keyfob Remote



- A Away button
- B Disarm button
- C Stay button
- D Auxiliary button
- E Key ring

Figure 2 4-Button Keyfob Remote—Battery Compartment



- 5 Replace the printed circuit board into the faceplate of the keyfob.
- 6 Replace the key ring in the space provided bottom of the fob. Then snap the keyfob faceplate and backplate closed.
- 7 Secure the screw into the back of the keyfob.

WARNING: Failure to follow these warnings and instructions can lead to heat generation, rupture, leakage, explosion, fire, or other injury, or damage. Do not insert the battery into the compartment in the wrong direction. Always replace the battery with the same or equivalent type (see *Specifications*). Never recharge or disassemble the battery. Never place the battery in fire or water. Always keep batteries away from small children. If batteries are swallowed, promptly see a doctor.

NOTE: Each of these devices requires one 3V lithium battery. Look, or ask, for CR2025 batteries at your favorite store.



"In GOD we trust, all others we monitor."

11426 Kingston Pike • Farragut, TN 37934

(865) 474-9495